


Rain gutter cleaning system Description

The gutter cleaning system removes leaves, dirt and other debris quickly and easily from the gutter without having to climb onto the roof. To do this, a flat-lying cleaning hose is inflated. Due to its expansion, the impurities are lifted and transported outwards over both sides of the rain gutter.




Assembly:

1. **Clean the rain gutter thoroughly.**
2. **Cut the cleaning hose** (length variable) [Blue] to the required length (length for the cut measured 5 cm from the drain pipe – see assembly instructions).
3. Shoot the cut end with a locking clip.
4. Position the valve side "A" in the direction of the drain.
5. Glue the cleaning hose (according to the installation instructions) into the rain gutter.
6. Screw the supply hose (length variable) [red] into the valve of the cleaning hose.

Routing of the supply hose:

Installation situation	Installation
Drain outlet via corridor	Feed the supply hose through the drain pipe of the rain gutter.
Drain outlet under floor	Attach the supply hose to the outside of the drain pipe. (We recommend cable ties)

Required tools for mounting:



Spray
Adhesive

Cleaning process:

Required tools for the cleaning process:




Bellows

or



Air Pump

or



Compressor

1. Connect the bellows, air pump or compressor to the bottom of the valve of the supply hose.
2. Inflate the cleaning hose.
3. The cleaning hose expands and pushes the contaminants upwards.
These slide left and right along the upper half of the hose over the edge of the rain gutter to the ground.
4. Disconnect the bellows, air pump or compressor from the valve and leave the supply hose **open**.

(The weight of the rainwater causes the air to escape from the cleaning hose, so that it becomes flat again and returns to its original position.)

This means that their rain gutter is clean again without having to climb onto the roof

Note:

The best cleaning result is achieved in light rain.

Due to the variable length of the supply hose, the height of the rain gutter does not matter.

The supply hose can be extended up to 100m. There's no need for a ladder, a lift, or an expensive cleaning company – and that's for the next 15 years of quality/manufacturer warranty.